## INSTALL GUIDE

**Determine** Height of the Post.

1

Adjust the Post to desired height & Twist to lock.

2

**Screw** the Post to object & **Nail** to formwork.







